



Hover-touch sensing with PSOC[™] 4 CAPSENSE[™]

About this document

Scope and purpose

This application note shows how to use PSOC[™] 4 MCUs with the 5th Generation CAPSENSE[™] technology and capacitive sensors to implement hover-touch sensing solutions.

Intended audience

This document is intended for developers, engineers, and designers who are interested in implementing hover-touch sensing solutions using Infineon's CAPSENSE[™] technology.

Note: This application note is for advanced users of CAPSENSE[™] technology who are familiar with PSOC[™] 4 devices, CAPSENSE[™] technology, CAPSENSE[™] Middleware Library. If the user is new to CAPSENSE[™] technology, see Getting Started with CAPSENSE[™] application note. For more information on CAPSENSE[™] in PSOC[™] 4, see PSOC[™] 4 and PSOC[™] 6 MCU CAPSENSE[™] Design Guide.



Table of contents

Table of contents

About this document				
Tabl	ole of contents	2		
1	Introduction			
2	CAPSENSE™ hover-touch sensing			
2.1	CAPSENSE [™] hover-touch sensor applications	5		
3	Associated content	6		
3.1	Supported devices	6		
3.2	Supported kits	6		
3.3	Online resources	6		
4	Designing the CAPSENSE™ hover-touch hardware	7		
4.1	Air gap distance	7		
4.2	Hover-touch button size	7		
4.3	Spacing between the hover-touch buttons	8		
4.4	Impact of nearby conductive objects	8		
4.5	Directionality	9		
4.6	Layout guidelines			
4.7	Noise tolerance			
4.8	Design considerations			
5	Developing the CAPSENSE™ hover-touch system firmware	12		
5.1	Hover-touch tuning guidelines	12		
Refe	erences	13		
Revi	vision history	14		
Disc	claimer	15		
		· · · · · · · · · · · · · · · · · · ·		



Introduction

1 Introduction

CAPSENSE[™] hover touch is a sensing technology that enables touch detection when the touch surface is elevated or is hovering above and the capacitive sensor pad.

Unlike traditional touch sensors that require direct contact with the surface or a strong dielectric medium between the touch surface and the sensing pad, hover touch leverages the highly sensitive capacitive sensing capability of Infineon's 5th Generation CAPSENSE[™] technology to detect touch interactions from a significant distance.

Features

The hover-touch sensing technology has the following features:

- Reduces overall sensor construction costing
- Supports multiple buttons placed close to each other
- Directional touch detection



CAPSENSE™ hover-touch sensing

2 CAPSENSE[™] hover-touch sensing

CAPSENSE[™] hover-touch sensors use the CAPSENSE[™] self-capacitance sensing technique, powered by the capacitive sigma-delta (CSD) system. This CSD touch-sensing method provides the industry's best-in-class Signal-to-Noise ratio (SNR).

Self-capacitance uses a single pin and measures the capacitance between the pin and nearby ground. In a CAPSENSE[™] self-capacitance system, the sensor capacitance measured by the controller is called C_s.

CAPSENSE[™] hover-touch sensors are conductive pads laid on a nonconductive material, such as PCB, plastic, or glass. The intrinsic capacitance of the PCB trace, pads, and other sensor connections is called the sensor parasitic capacitance (C_P). This C_P is related to the electric field around the sensor pads.

When a finger is not near the sensor:

Sensor capacitance (C_S) = Parasitic capacitance (C_P) of the system

Equation 1

Figure 1 shows coupling of the field lines around the sensors when there is no target object such as a finger present.



Figure 1 Sensor parasitic capacitance and electric field

When the target object approaches the sensor, a small amount of finger capacitance (C_F) is added to the C_P due to some of the electric field lines from the sensor getting coupled to the finger. Hence, the sensor capacitance becomes:

Sensor capacitance (C_S) = Parasitic capacitance (C_P) + Finger capacitance (C_F)

Equation 2

This change in capacitance is measured by the CAPSENSE[™] system to detect the touch of the finger as shown in Figure 2.



CAPSENSE™ hover-touch sensing



Figure 2 Illustration of electric field lines coupling to finger

2.1 CAPSENSE[™] hover-touch sensor applications

A hover-touch sensor is a capacitive touch button with the overlay elevated from the PCB. This implementation eliminates the need for the gap to be bridged using a conductive material (typically a spring or conductive foam). Additionally, this reduces the overall construction cost.

CAPSENSE[™] hover-touch sensors can be used in several home appliances like:

- Washing machines
- Microwave ovens
- Refrigerators
- Air conditioners



Figure 3 Advantage of using hover-touch button



Associated content

3 Associated content

The following section provides the supporting resources relevant to this application note.

3.1 Supported devices

• PSOC[™] 4000T

3.2 Supported kits

• CY8CPROTO-040T-MS

3.3 Online resources

- CAPSENSE[™] sensing controller webpage
- ModusToolbox[™] software help on Github
- AN79953 Getting Started with PSOC[™] 4
- Getting Started with CAPSENSE™
- PSOC[™] 4 and PSOC[™] 6 CAPSENSE[™] design guide
- Eclipse IDE for ModusToolbox[™] user guide
- ModusToolbox[™] CAPSENSE[™] Configurator user guide
- ModusToolbox[™] CAPSENSE[™] Tuner user guide
- CAPSENSE[™] Middleware Library Documentation



4 Designing the CAPSENSE[™] hover-touch hardware

This section describes the various hardware aspects that need to be considered when designing the hover touch sensor buttons.

See the Supported devices section for a list of compatible parts.

4.1 Air gap distance

Air gap distance (L_{air}) is the primary consideration when designing a hover-touch button. Depending on the usecase and project, this requirement must be defined first. It represents the distance between the hover-touch sensor pad and the overlay surface that will be touched.



Figure 4 Air gap between the hover-touch button and finger touch

4.2 Hover-touch button size

Hover-touch button size refers to the dimensions of the conductive pad that forms the touch sensor. The size of the button directly affects the maximum distance from which the hover-touch button can detect a contact. Larger buttons can detect touch from greater distances, while smaller buttons are limited to shorter distances.

The thumb rule is that the button size should at least be equal to the air gap distance. For example, if the air gap distance is 10 mm, the radius of a round button should be at least 10 mm.





Figure 5 Size of the hover-touch button with respect to the air gap

4.3 Spacing between the hover-touch buttons

This parameter is crucial to ensure that each button can function without interfering with its neighboring buttons. Due to the high sensitivity of hover-touch buttons, placing two buttons too close together can cause one button to inadvertently trigger the other (crosstalk).

To prevent crosstalk, there should be ample space between the buttons. The recommended spacing between the buttons is equal to the button size itself. For example, if a round button has a diameter of 10 mm, the adjacent button should be at least 10 mm away from the edge of the first button, as shown in Figure 6.



Figure 6 Spacing between the hover-touch buttons

4.4 Impact of nearby conductive objects

Nearby conductive objects can absorb a part of the electrical field, thereby reducing the detection range of the hover-touch sensors. Coupling of sensor electric field lines to nearby conductive/ground objects increases the sensor's parasitic capacitance (C_P) and consequently decreases the sensitivity of the hover-touch sensors.

To mitigate this impact:

- Ensure that the conductive object is placed from the sensor
- A shield is used between the object and the sensor. If feasible, use the object as a shield

The concept of shielding is outlined in Section 4.6.

Application note



4.5 Directionality

Due to the highly sensitive nature of a hover-touch sensor, it can detect touches from unintended directions. Implementing directional sensing in an end system poses a significant challenge, as it relies on factors such as overall enclosure design, hardware components, and PCB layout.

The placement of a ground plane at the bottom of the sensors removes the possibility of unintended touches coming from below and achieves directional sensitivity in hover-touch sensors. Since the ground plane can decrease the sensor's sensitivity, it must be placed with some separation from the sensor PCB. The optimal distance depends on various system factors and requires testing on the actual system to determine the best distance.

However, it is recommended to keep the separation at least 30% of the air gap as shown in Figure 7. The separation can be increased gradually if the desired sensitivity is low.



Figure 7 Spacing between PCB and GND plane

Figure 8 shows a real-time example of a hover-touch sensing stack-up, including the PCB, ground plane, and overlay.



Figure 8 The stack-up of the layers of the hover-touch sensing system

Note: In systems that include a ground chassis, the ground plane is not required, as the ground chassis can fulfill the same function.



4.6 Layout guidelines

Layout guidelines for hover-touch sensors are similar to designing the CSD capacitive button sensors. For details, refer to Section 7.4 and Section 2.5.1.2 of AN85951 - PSOC[™] 4 and PSOC[™] 6 MCU CAPSENSE[™] design guide.

Additionally, keep the following guidelines in mind:

- **Trace length:** The lesser the length of the traces running on the PCB from the microcontroller GPIO to the hover-touch sensor pads, the better the sensitivity of the hover-touch sensors. Hence, it is recommended to minimize the sensor trace length
- **Shielding:** The stray parasitic capacitance (C_p) of each sensor directly impacts the sensitivity of the hovertouch sensors. The C_p can increase due to nearby ground planes, ground traces, idle electrodes, etc. This high C_p decreases the sensitivity of the hover-touch sensors

To keep the C_p of the hove- touch sensor low, shielding is necessary. A shield is implemented by pouring a hatch-patterned copper around the hover-touch sensor and driving this shield with the signal that is identical to the hover-touch scanning signal. This shield can be driven with a dedicated GPIO, which is configured while developing the firmware.

It is recommended to shield the hover-touch sensor all around to achieve high sensitivity. The minimum gap between the hover-touch button and the shield should be 1 mm. Figure 9 illustrates placing the shield around the hover-touch sensors.



Figure 9 Spacing between PCB and GND plane

4.7 Noise tolerance

CAPSENSE[™] hover-touch sensors are susceptible to noise because of their large sensor area and high sensitivity setting. High noise makes it difficult to achieve a good signal-to-noise ratio (SNR) (typically greater than 5:1), which is required for the hover-touch sensing system.

Table 1 lists the common sources that contribute to noise in hover-touch sensing and their respective recommended mitigation techniques.



Noise source	Examples	Recommended noise mitigation technique			
PWM driven devices	LEDs, motors	• Design to keep these sources as far as			
Switching power converter	AC-DC, DC-DC, DC-AC	 possible from the sensor Add a ground hatch between these devices and sensors 			
High-speed communication interfaces	USB, Ethernet	 Use shielded twisted pair wires Design to keep these sources as far as possible from the sensor Add a ground hatch between these devices and sensors 			
AC supply lines	Relays and switches	• Use shielded twisted pair wires when power lines are passing near the sensors			

Table 1 Sources of noise and mitigation techniques

4.8 Design considerations

Table 2Design considerations

Parameter	Recommendation
Button Size	Greater or equal to air gap
Button Spacing	Greater or equal to air gap
Ground plane separation	Greater than 30% of air gap



Developing the CAPSENSE[™] hover-touch system firmware

5 Developing the CAPSENSE[™] hover-touch system firmware

This section assumes that the user is familiar with PSOC[™] 4 devices, CAPSENSE[™] technology, CAPSENSE[™] Middleware Library, including the CAPSENSE[™] Configurator, and Tuner software tools. For more information, refer to Associated content.

The code example PSOC[™] 4: MSCLP CAPSENSE[™] Hover Touch 4 helps learn how to develop the firmware for the hover-touch system.

Prerequisites:

• Install ModusToolbox™

5.1 Hover-touch tuning guidelines

The primary tuning guidelines are mentioned in the **Tuning Procedure** section of the code example PSOC[™] 4: MSCLP CAPSENSE[™] Hover Touch. The code example is tuned for the kit(s) mentioned in Section 3. However, for hover-touch, there are a few additional considerations to ensure optimal sensitivity and SNR.

- Number of sub conversions (Nsubs): This is the primary parameter that influences the signal strength, sensitivity, and effective SNR of the hover-touch sensors. Higher the Nsubs, higher the SNR and sensitivity. Hover-touch applications require high sensitivity, and adjusting Nsubs plays a significant role in achieving this. However, increasing Nsubs also increases the scan time, hence impacting the response time of the hover-touch sensors. Fine-tuning this parameter is essential to reach an optimal case with a decent SNR and a good response time
- **CDAC Boost:** This parameter can also be used to increase the signal strength. It can further amplify the signal when increasing the Nsubs is not sufficient and a higher signal level is required. Note that while CDAC Boost increases the signal strength, it also raises the noise level. Therefore, it is essential to fine-tune this parameter alongside Nsubs to find the optimal balance between signal strength and noise
- **Filters:** A significant way to reduce noise is to enable filters, which greatly enhances the SNR, making the sensing robust and reliable

The CAPSENSE[™] ecosystem features the following types of filters:

- Hardware filters: CIC2, HW-IIR
- Software filters: SW-IIR, Average, Median

For details of how the above filters work and affects the signal, refer to **Table 10** of the AN85951 - PSOC[™] 4 and PSOC[™] 6 MCU CAPSENSE[™] design guide. To enable the filters, refer to the section **Fine tune for** required SNR of the code example PSOC[™] 4: MSCLP CAPSENSE[™] Hover Touch

While filters can improve noise reduction, they can also increase the response time, potentially making the hover-touch buttons less responsive. A good balance between noise reduction and response time is very important while enabling the filters

• **Thresholds:** When the appropriate SNR is achieved with a decent response time, thresholds are required to be set to determine the trigger points for touch detection. Tune the thresholds so that all intended button touches are properly triggered without being affected by the other buttons.

Due to the highly sensitive nature of hover-touch sensors, they tend to get triggered by touch on other neighboring hover-touch buttons, commonly called as cross talk. Cross talk is common and should not be treated as a problem. Fine-tuning the thresholds can effectively eliminate cross talk, ensuring clean and intended button triggering



References

References

- [1] Infineon Technologies AG: AN64846 Getting Started with CAPSENSE™. Rev AA; Available online
- [2] Infineon Technologies AG: AN85951 PSOC[™] 4 and PSOC[™] 6 MCU CAPSENSE[™] Design Guide. Rev AG; Available online
- [3] Infineon Technologies AG: Proximity sensing with CAPSENSE[™]; Available online



Revision history

Revision history

Document revision	Date	Description of changes
**	2025-02-14	Initial release

Trademarks

All referenced product or service names and trademarks are the property of their respective owners.

Edition 2025-02-14 Published by

Infineon Technologies AG 81726 Munich, Germany

© 2025 Infineon Technologies AG. All Rights Reserved.

Do you have a question about this document? Email: erratum@infineon.com

Document reference 002-41091 Rev. **

Important notice

The information contained in this application note is given as a hint for the implementation of the product only and shall in no event be regarded as a description or warranty of a certain functionality, condition or quality of the product. Before implementation of the product, the recipient of this application note must verify any function and other technical information given herein in the real application. Infineon Technologies hereby disclaims any and all warranties and liabilities of any kind (including without limitation warranties of non-infringement of intellectual property rights of any third party) with respect to any and all information given in this application note.

The data contained in this document is exclusively intended for technically trained staff. It is the responsibility of customer's technical departments to evaluate the suitability of the product for the intended application and the completeness of the product information given in this document with respect to such application.

Warnings

Due to technical requirements products may contain dangerous substances. For information on the types in question please contact your nearest Infineon Technologies office.

Except as otherwise explicitly approved by Infineon Technologies in a written document signed by authorized representatives of Infineon Technologies, Infineon Technologies' products may not be used in any applications where a failure of the product or any consequences of the use thereof can reasonably be expected to result in personal injury.